Safety Precautions

In order to prevent any accidents happening, must follow the instructions below as you are using this product:

- The instructions of this manual are for users applying this product correctly, and preventing damage or property loss to users or others.
- "WARNING" is central contents for preventing any accidents happening, please follow cautiously.

⚠ WARNING

- Stop using the product immediately and unplug once smoke, smell, noise, or other unusual situations appear; it is very possible to cause fire hazard or electric shock, if the product operates continuously.
- Do not alter, repair or dismantle this product on your own, it may cause fire hazard, electric shock, malfunction or injury.
- Please follow local regulations when you are discarding consumables.
- Please ensure to use the actual cable (5V/1A), or may cause the malfunction.
- Use the USB cables enclosed with the products; do not use other's brands cable, as this may cause the malfunction.
- Do not connect the power during installation, as electric shock and injury may occur.
- While unplugging the power card, please hold it tight or may cause damage to the power cord.
- If power cord or plug is damaged, or the product is dropped, hit, damaged, or broken, stop using it, this is possible to cause electric shocks or short circuit.
- Do not operate this product with wet hands, or drip or spill water or other liquids onto the product. These may cause electric shock or injuries.
- Do not deliberately place your eyes, nose or mouth close to the fragrance mist emitted as this may cause physical discomfort.
- Do not put fingers or hands into the product.
- In order to avoid any danger or accidents, parents guard is necessary when children use this product.
- Please follow the instructions to use this product; it is possible to result in poisoning or fire hazard, if other substances are used. Do not immerse this product in water, this product is for household use only.
- This product is not intended for use by persons（including children）with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible.
- Do not let children use this product alone, keep it out of reach of children, or it may cause electric shocks or injuries.
- To avoid fire hazard, electric shocks, injuries or malfunction, please do not keep this product in the following places:
  - Under direct sunlight or high temperature environments, and keep away from fire sources.
  - Places with high pressure or flammable materials.
- Do not place the product on soft surfaces such as carpet, as this may block the ventilation inlet on the bottom of the unit, causing the device to not function correctly.
- Do not over bend, heat, or place heavy objects on the power cord, or it may cause fire hazard or malfunction.
- If an extension cord is used, please pay attention to the introductions to electric appliances using. The specifications should be the same. The cord should be placed at evident places to avoid children pulling or stumbling.
- In order to prevent accidents happening, if the power cord is damaged, please replace it via the manufacturer, other service departments, or staffs who own related qualifications.

Troubleshooting

If you experience unsatisfactory operations, please follow our troubleshooting guidelines listed below.

- Power Indicator flashes
  →When power indicator flashes, indicates low battery, please plug in the power cord and use after charging.
- Diffuser has fully charged, still not functioning
  →Please ensure that diffuser is power on, power indicator is lighted on; if flashes, indicates low battery, please plug in the power cord to charge and use.
- Unable to charge
  →Please ensure the power cord is plugged in correctly, power indicator flashes when it is charging.

Product Specification

Aroma diffusing performance may vary due to ventilation, humidity, size of the spaces.
Product's Name: Portable Aroma Diffuser
Product's Size: W 9 X D 7 X H 3.8 cm
Product's Weight: 126 g
Recommend using space: 1-2 square meters
Charging time: 60 min
Continuous using time: 8.5 hours (fully charged)
Accessories: main unit x1, paper pad x4, wrist strap x1,USB Power cord X1, instruction manual, warranty card
Design: SERENE HOUSE
MADE IN CHINA

Do not attempt to dismantle or repair the product by yourself. If the unit still does not operate satisfactorily, please contact with SERENE HOUSE customers service or local shop.
Service Line: +886 2 7721 8848

Warranty Card

SERENE HOUSE is providing 1 Year Warranty Service, please keep this Warranty card properly (Will not reissue one another if missing), or you can register your product's warranty on our website to guarantee your product's warranty rights.To register your product's warranty→https://www.serenehouse.tw/forms/product-registration

1. Customer should follow the instruction to use the product, if the product is malfunction during Warranty Period, please keep your Warranty card and Receipt, to apply for maintenance services, we will repair or replace a new one for you.
2. Under these situations, there will be additional charge even though it is in Warranty Period.
   - Fire Hazzard, Broken, Gas explosion, Earthquake, Windstorm, Flood, Thunder, Abnormal Voltage, Natural disasters or Force Majeure that cause product to breakage or malfunction.
   - Content of Warranty Card is incomplete, alters, or not able to provide a valid purchase evidence.
   - Discolor, scars, stains and improper keeping that cause product to malfunction.
   - Replacement consumable accessories (batteries, remote control, cleansing brush)
3. When you need your product to be repaired, please register from website or contact to local distributor, we will contact you as soon as possible.Maintenance Request Form→https://www.serenehouse.tw/forms/repair-application

Customer Info			
Name	Mr / Mrs	Phone	
Address			
E-mail			
Product Info			
Name			
Model			
Manufacturer Code			
Retailer			
Purchase Date	Y M D		
Warranty Period	12 Months After Purchase (Not including consumable accessories)		

Website | Product Registration | Maintenance Request Form

- Customer Service's Phone Number: (02) 7721-8848
- Customer Service's Email: service_tw@serene-house.com

注意事項

為了預防使用時發生意外，請務必遵守以下事項：

- 本使用說明書的注意事項，是為了讓使用者能正確的使用本產品，防止對使用者或他人造成危害及財產損失。
- 警告事項皆為預防意外發生的重要內容，請務必遵守。

⚠ 警告

- 萬一出現冒煙、異味、雜音等異常現象時，如繼續使用的話可能導致火災、觸電等，請立即關 閉電源，並移除電源線，停止使用。
- 請勿擅自對本產品進行改造、修理或拆解，否則有可能造成火災、觸電、故障或受傷。
- 耗材廢棄時，請遵照各國法規。
- 請使用5V/1A規格之充電器，否則將導致機器故障。
- 請使用本產品所附之USB電源線，如使用他牌電源線，可能會引發機器故障。
- 本產品長期不用時，請關閉電源並移除電源線，否則可能造成機器故障。
- 拔下電源線時，請勿拉扯，必須緊握接頭後再拔除，否則有可能造成電源線破損或人員受傷。
- 當電源線破損時，或是產品不小心摔落或受到撞擊而受損或破裂時，不得繼續使用本產品，否則有可能造成觸電、短路等問題。
- 請勿用濕的手操作本產品，或讓水等其他液體沾附、漸灑到上面，否則有可能造成觸電受傷。
- 請勿故意將眼口鼻靠進出霧口所排出的香氛霧氣，否則有可能造成身體不適。
- 請勿在本產品運作時將手或手指放置於本產品之內。
- 為避免危險，幼童須在成年人監督下使用產品，預防意外發生。
- 錯誤使用本產品，將可能導致火災等意外，請依指示使用本產品，若使用其他介質將可能 引發中毒或火災等危險。
- 請勿將本產品浸入水中；本產品僅供空間香氛使用。
- 除非有專業人士的督導和指示，本產品不適合由身體、感官或精神能力欠佳，或缺乏經驗及知識的人士使用（包括兒童）。
- 建議放在幼童與寵物觸及不到的地方，避免意外發生。
- 請勿將本產品放置在以下地方，否則有可能引起火災、觸電、受傷、故障：
  -陽光直射或高溫環境，或靠近火源。
  -高壓物及易燃物周圍。
- 請勿將電源線過度彎折、加熱或上方放置重物，否則有可能引起火災或故障。
- 若電源線損壞時，請由製造廠或其他服務處或具有相關資格的人員加以更換以避免危險。

障礙排除

疑似故障時，請在委託維修前確認以下事項：

- 電源指示燈閃爍
  → 當電源指示燈閃爍時，顯示為電量過低，請先接上電源線或充電後再使用。
- 機器已充電，但仍然不會運作
  → 請先確認機器開啟後，電源指示燈是否常亮，如閃爍，則為電量過低，請先接上電源線或充電後再使用。
- 無法充電
  → 請確認電源線是否正確接上主體的電源孔，正常充電狀態下，電源指示燈會閃爍。

產品規格

擴香效果會因空間通風度、溫濕度及空間大小而有所變化。
產品名稱： 隨行香氛機
產品尺寸：W 9 X D 7 X H 3.8 cm
產品重量：126 g
建議使用空間：1-2 平方公尺
充電時間：60分鐘
連續使用時間：8.5小時（滿電狀態）
配件： 主機X1、紙片X4、吊繩X1、USB電源線X1、說明書、保證書
設計： SERENE HOUSE
中國製造

如產品出現其它故障，請聯繫SERENE HOUSE官方客服或請與專賣店聯繫。
請勿自行動手拆解或維修本產品。
服務專線：+886 2 7721 8848

產品保證書

SERENE HOUSE提供一年保固服務，請妥善保管本產品保證書（遺失恕不補發），或可於購買商品後上品牌官網提交產品保固登錄，確保您的商品保固權益。
產品保固登錄→https://www.serenehouse.tw/forms/product-registration

1. 顧客依照使用說明書，於正常使用情況下，在保固期間內發生故障時，請備妥商品、本保證書及產品購買憑證（如發票、訂購單據等），申請維修服務，我們將為您免費修理或換新。
2. 若出現下列情況，雖在保固期限內仍須採取額外報價付費修理：
   - 錯誤使用方式或不當的修理與改造所造成的故障或損傷。
   - 火災、損害、煤氣或天然氣爆炸、地震、風災、水災、打雷、電壓異常及其他天災或不可抗外力因素所造成的故障及損壞。
   - 保證書內容不完整、經人為塗改，或未能提供有效購買憑證。
   - 產品使用後的傷痕、變色、汙損及保管不當所造成的損壞。
   - 損耗性零件及配件的更換（如震盪片、清潔刷、電池、遙控器等）。
3. 當您需要維修產品時，可先於官網提交維修申請，我們將盡速為您服務。
   維修申請→https://www.serenehouse.tw/forms/repair-application

顧客資料			
姓　名	先生 / 女士	電　話	
通訊地址			
E-mail			
商品資訊			
商品資訊			
商品名稱			
型　號			
生產序號			
銷 售 商			
購買日期	年　月　日		
保固期間	自購買日起12個月（不含耗材）		

官方網站 | 產品登錄 | 維修申請

- 客服專線：（02）7721-8848
- 客服郵箱：service_tw@serene-house.com

注意事项

为了预防使用时发生意外，请务必遵守以下事项：

- 本使用说明书的注意事项，是为了让使用者能正确的使用本产品，防止对使用者或他人造成危害及财产损失。
- 警告事项皆为预防意外发生的重要内容，请务必遵守。

⚠ 警告

- 万一出现冒烟、异味、杂音等异常现象，如继续使用可能会导致火灾、触电等，请立即关闭电源，并移除电源线，停止使用。
- 请勿擅自对本产品进行改造、修理或拆解，否则有可能造成火灾、触电、故障或受伤。
- 耗材废弃时，请遵照各国法规。
- 请使用5V/1A规格之充电器，否则将导致机器故障。
- 请使用本产品所附之USB电源线，如使用他牌电源线，可能会引发机器故障。
- 本产品长期不用时，请关闭电源并移除电源线，否则可能造成机器故障。
- 拔下电源线时，请勿拉扯，必须紧握接头后再拔除，否则有可能造成电源线破损或人员受伤。
- 当电源线或插头破损时，或是产品不小心摔落或受到撞击而受损或破裂时，不得继续使用本产品，否则有可能造成触电、短路等问题。
- 请勿用湿的手操作本产品，或让水等其他液体沾附、溅洒到上面，否则有可能造成触电受伤。
- 请勿故意将眼口鼻靠进出雾口所排出的香氛雾气，否则有可能造成身体不适。
- 请勿在本产品运作时将手或手指放置于本产品之内。
- 为避免危险，幼童须在成年人监督下使用产品，预防意外发生。
- 错误使用本产品，将可能导致火灾等意外，请依指示使用本产品，若使用其他介质将可能引发中毒或火灾等危险。
- 请勿将本产品浸入水中；本产品仅供空间香氛使用。
- 除非有专业人士的督导和指示，本产品不适合由身体、感官或精神能力欠佳，或缺乏经验及知识的人士使用（包括儿童）。
- 建议放在幼童与宠物触及不到的地方，避免意外发生。
- 请勿将本产品放置在以下地方，否则有可能引起火灾、触电、受伤、故障：
  – 阳光直射或高温的环境，并远离火源。
  – 高压物及易燃物周围。
- 请勿将电源线过度弯折、加热或上方放置重物，否则有可能引起火灾或故障。
- 若电源线损坏时，请由制造厂或其他服务处或具有相关资格的人员加以更换以避免危险。

障碍排除

疑似故障时，请在委托维修前确认以下事项：

- 电源指示灯闪烁
  → 当电源指示灯闪烁时，显示为电量过低，请先接上电源线或充电后再使用。
- 机器已充电，但仍然不会运作
  → 请先确认机器开启后，电源指示灯是否常亮，如闪烁，则为电量过低，请先接上电源线或充电后再使用。
- 无法充电
  → 请确认电源线是否正确接上主体的电源孔，正常充电状态下，电源指示灯会闪烁。

产品规格

扩香效果会因空间通风度、温湿度及空间大小而有所变化。
产品名称： 随行香氛机
产品尺寸：W 9 X D 7 X H 3.8 cm
产品重量：126 g
建议使用空间：1-2 平方公尺
充电时间：60分钟
连续使用时间：8.5小时（满电状态）
配件： 主机X1、纸片X4、吊绳X1、USB电源线X1、说明书、保证书
设计： SERENE HOUSE
中国制造

如产品出现其它故障，请联系SERENE HOUSE官方客服或请与专卖店联系。
请勿自行动手拆解或维修本产品。
服务专线：+86 400–885–3268

产品保修卡

为确保您的权益，请妥善保管本产品保修卡（遗失恕不补发）。如需服务时请出示本保证书，依照下列刊载之内容，提供免费维修。

1. 顾客依照使用说明书，于正常使用情况下，在保固期间内发生故障时，请带着商品与本保证书，即可委托原购买门市代为修理，此属免费修理。
2. 若出现下列情况，虽在保固期限内仍须采取额外报价付费修理：
   - 错误使用方式或不当的修理与改造所造成的故障或损伤。
   - 火灾、损害、煤气或天然气爆炸、地震、风灾、水灾、打雷、电压异常及其他天灾或不可抗外力因素所造成的故障及损坏。
   - 保证书上未注明顾客姓名、购买日期及购买门市，或是保证书内容经人为涂改时。
   - 使用后的伤痕、变色、污损及保管不当所造成的损坏。
   - 损耗性零件及配件的更换（如震荡片、清洁刷、电池、遥控器等）。

顾客资料			
姓　名	先生 / 女士	电　话	
地　址			
E –mail			
商品信息		专卖店店章盖章处（请务必盖章）	
商品名称			
型　号			
生产序号			
销 售 商			
购买日期	年　月　日		
保修期间	自购买日起12个月（不含耗材）		

东莞静庐商贸有限公司
广东省东莞市虎门镇基智北路5号2栋
service@serenehouse.com.cn
+86 400 885 3268

◆ 栏目填写不清、不实或空白时，本保修卡无效，请填写姓名、电话与地址；如未填写购买日期与加盖专卖店店章，请立即向购买本商品的门市提出填写要求，本保修卡只附赠一次，请务必小心保管，遗失恕不补发。