


Serene Pod® Scent Diffuser

- This instruction is suitable for Ufo, Aerolite and Eclipse.




Ufo

Inspired by the saucer – a traditional Chinese container – Ufo lands on your desk and creates clouds of pure natural scents for the space.



Aerolite

Place a Serene Pod® in the base of the Aerolite, close your eyes and be surrounded by your favorite scent. You might find yourself drifting around the universe with fantasy.




Eclipse

With the inspiration of a solar Eclipse shape and its amazing corona. Enjoy a celestial phenomenon at home.


Product & Accessories

- Serene Pod® is required to be used with this product. Serene Pod® is sold separately.



Operating Instructions

- Please remove all packaging before use.




Caution:

- Only Serene Pod® from SERENE HOUSE can be used with this product; do not heat liquids or other objects on the heating plate.
- Serene Pod® can be heated repeatedly. If the scent fades or the diffusing performance drops, please consider replacing the Serene Pod®. The Serene Pod® is a consumable item; please contact your local distributor for purchase.
- Do not move or touch when this product is in use. Allow the wax inside Serene Pod® to cool thoroughly into a solid form before handling the device or Serene Pod®.
- Unplug from power source when not in use.
- Always place this wax warmer on a firm, flat and level surface.

Cleaning & Maintenance

- Always disconnect the product from its power source prior to cleaning & maintenance.
- Allow to dry thoroughly before use.
- Never soak or wash this product directly as it may cause mechanical malfunction or danger.
- Never use acidic cleansing agents as it may cause malfunction to the product.
- Please perform cleaning & maintenance at least once a week; failing to do so may cause the product to malfunction. Please maintain it on a regular basis.



Specifications

- Fragrance results may vary depending on ventilation, temperature, humidity, and the size of space.

Ufo

Model code : 121205001 White / 121205002 Black
Suggested room size : 15 ~ 35 m² (161.4 ~ 376.7 sq ft)
Power input : 100 - 240 V ~, 50 / 60 Hz, 8W
Product size : Φ 11.7 cm x 7.3 cm H (Φ 4.6 in x 2.9 in H)
Main unit weight : 380 g (13.4 oz)

Aerolite

Model code : 121205005 White / 121205006 Black
Suggested room size : 15 ~ 35 m² (161.4 ~ 376.7 sq ft)
Power input : 100 - 240 V ~, 50 / 60 Hz, 8W
Product size : Φ 13.6 cm x 6.6 cm H (Φ 5.4 in x 2.6 in H)
Main unit weight : 450 g (15.9 oz)

Eclipse

Model code : 121205003 White / 121205004 Black
Suggested room size : 15 ~ 35 m² (161.4 ~ 376.7 sq ft)
Power input : 100 - 240 V ~, 50 / 60 Hz, 8W
Product size : Φ 15 cm x 13.7 cm H (Φ 5.9 in x 5.4 in H)
Main unit weight : 760 g (26.8 oz)

Operation mode : Continuous mode
Accessories included : AC adaptor and Warranty card.
Designer : Peter Wirz
Design supervised by : Carsten Jörgensen
Design : Switzerland / Taiwan
Made in China

Precautions for Use

- Please read all instructions before using the product. Use it safely and correctly.
- Be sure to handle this product with care to avoid impacts or drops.
- If you have any special physical conditions, such as pregnancy, lung failure, cancer, epilepsy, or other illnesses, please consult your doctor before use.

Precautions for Use of Serene Pod®


- Do not remove or damage the transparent micro perforated film of the Serene Pod® in order to avoid spillage of melted scented wax.
- Please do not touch Serene Pod® when it is being heated to avoid accidental burns.
- Please keep children and pets away from Serene Pod® to prevent accidental ingestion.
- Serene Pod® is not edible; please do not eat it.
- Stop using the product and open the windows for ventilation if you start to feel uncomfortable.
- Replace with a new Serene Pod® to ensure best scent ability if the aluminum foil cup of Serene Pod® is deformed in any way (including the bottom).


Safety Precautions


Make sure to follow the instructions below to ensure safe usage:


- The precautions listed in this manual are to ensure safe and proper use of this product by the user, and to avoid any danger or loss that might occur to the user or others.
- "WARNING" contains important safety instructions. Be sure to follow these instructions.


WARNING

-  • Stop using the product immediately and unplug the AC adapter once smoke, smell, unusual sounds or other anomalies occur.

-  • Do not modify, fix, or dismantle this product, as fire, electric shock, damage or injuries may occur.

-  • When the product is at the end of its life, we recommend disposal at a collection point for the recycling of electrical and electronic equipment, rather than with household waste. The symbols on the product, instruction manual and packaging allow for proper sorting and disposal.

-  • Please use the proper voltage as required by the product.
- When this product is not used for long periods of time, make sure to unplug it from the power source and remove Serene Pod® from the heating plate; failure to do so may result in electric shocks or malfunction.
- The product must be disconnected from the power source prior to cleaning and maintenance.
- Once all power sources are disconnected, allow Serene Pod® to cool thoroughly into a solid form before handling, cleaning and maintenance.
- If the liquid wax accidentally dripped onto objects such as the device or the floor, wipe clean with a damp cloth immediately to avoid discoloration of the exterior of the product or the furniture.

-  • Do not use the product when cord or plug is damaged or the product has been accidentally hit, dropped, broken or damaged in any way as such actions may cause problems such as electrical shocks or short circuiting.
- Do not operate this product with wet hands, or allow water or other liquids to drip or spill onto the product as these may cause electric shock or injuries.
- Do not power on the device when there is no Serene Pod® in the heating plate, doing so may cause the product to malfunction.
- Do not put your finger or any other objects into the heating plate while the product is in use, doing so may cause personal injuries or product malfunction.
- This product is not a toy. Do not let children use this product. Keep out of reach of children as electric shock and injury may occur. Children should be supervised to ensure that they do not play with the product.
- To avoid fire, electric shock, personal injuries or product damage, do not place the product in the areas listed below :
 - Under direct sunlight or high temperature environments, and keep away from fire sources
 - Places with high pressures or around combustible objects.
- Do not bend, heat, or place heavy objects on the power cord as fire or malfunction may occur.



Patent Product

Troubleshooting

When the product is suspected of malfunctioning, please confirm the following items before sending it in for maintenance :

Machine does not operate

- AC adapter is not properly inserted into the socket.
 - Please make sure that the AC adapter is properly inserted into the socket.
- The plug of the AC adapter is not properly plugged into the power socket of the main unit.
 - Please make sure that the plug of the AC adapter is properly plugged into the power socket of the main unit.

Poor Fragrance Emission

- The scent fades or the transparent micro perforated film is damaged
 - Please replace the Serene Pod® with a new one.
- The heating plate is dirty
 - Perform maintenance according to the Cleaning & Maintenance section of this manual.

Do not attempt to dismantle or repair the product by yourself. If the unit still does not operate satisfactorily, please visit our website www.serenehouse.com, and click link "Support", or contact our customer service.

SERENE  HOUSE®

Instruction Manual



Serene Pod® Scent Diffuser

Ufo • Aerolite • Eclipse