


SERENE HOUSE®

Serene Pod® Wax Warmer

Instruction Manual



Foliage

IMPORTANT SAFETY INSTRUCTIONS

In order to ensure safety and correct usage, please read all the safeguards below as using electric products every time.


⚠ Attention

Must follow the safeguards below as using this product every time.

- Read all instructions carefully before using this product for the first time.
- Do not put fingers or hands into the product.
- In order to avoid any danger or accidents, parents guard is necessary when children use this product.
- If the power cord is damaged, do not keep using this product.
- Using this product inappropriately may cause fire hazard. Please follow the instructions to use this product; it is possible to result in poisoning or fire hazard, if other substances are used. Do not immerse this product in water, this product is for household use only.
- If an extension cord is used, please pay attention to the introductions to electric appliances using. The specifications should be the same. The cord should be placed at evident places to avoid children pulling or stumbling.
- In order to prevent accidents happening, if the power cord is damaged, please replace it via the manufacturer, other service departments, or staffs who own related qualifications.
- This product is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible.
- Children should be properly supervised to ensure that they will not play with this product at all times. Keep out of reach of children and pets as electric shock and injury may occur.

Product & Accessories

· Serene Pod® is required to be used with this product. Serene Pod® is sold separately.



(The image is for reference only. Actual product may vary.)

Operating Instructions

· Please remove all packaging before use. (Please do not tear up the woven membrane of Serene Pod®.)
· Performance may vary due to room's size, ventilation and humidity.


1	Remove plastic Lid.	2	Properly place the Serene Pod® onto the heating plate.
3	Plug the head of the USB power cord into the power jack. Plug USB end of power cord into any USB port.	4	Connect power source, press the power button to begin continuous operation. Press the power button again to turn off the device. ※ Automatic safety shut off every 9 hours.
5	Light Instructions: While the device is on, the power indicator stays on, long press the power button for 2 seconds to turn on/off the ambient light.		

· Please read all instructions carefully before using the product.
· This product is only suitable for Serene Pod®, do not put liquids or other substances into the heating plate.
· Serene Pod® can be heated repeatedly. If the scent fades or the performance drops, please replace new Serene Pod®. Serene Pod® is consumable; please contact your local distributor for more information.
· Stop using the product and open the windows for ventilation. If you have difficulty breathing due to allergic reaction or any special physical conditions, such as pregnancy, lung failure, cancer, epilepsy or other illnesses, please consult your doctor before using this product.

SERENE HOUSE®

香氛膠囊機

操作使用說明書



映葉

重要警告事項


⚠ 注意！

當使用此電器產品時，必須按照下列排序的警告事項執行：

- 使用此產品前請詳閱使用說明書。
- 請勿在本產品運作時將手或手指放置於本產品之內。
- 當電源插頭損壞時，請勿繼續使用本產品。
- 錯誤使用本產品，將可能導致火災的意外，請依指示使用本產品，若使用其他介質將可能引發中毒或火災的危險；請勿將本產品浸入水中，本產品僅供室內使用。
- 本產品可接延長線使用，使用時請注意。
- 連接延長線時，請注意所使用的電器規格，至少與產品規格相同。
- 為安全起見，壁插式香氛膠囊機的電源插頭有大小之分，如果插頭無法完全插入插座時，請轉換插頭方向，若插頭仍然無法接通電源插座，請諮詢專業合格的電工人員，切勿自行處理。
- 若電源插頭損壞時，請由製造廠或其他服務處或具有相關資格的人員加以更換，以預防意外發生。
- 除非有專業人士的督導和指示，本產品不適合由身體、感官或精神能力欠佳，或缺乏經驗及知識的人士使用（包括兒童）。
- 孩童應受監護，以確保孩童不嬉玩電器。建議放在孩童與寵物觸及不到的地方，避免意外發生。

產品與配件介紹

· 本產品僅能搭配使用 SERENE HOUSE 香氛膠囊蠟 Serene Pod®，香氛膠囊蠟為單獨販賣商品。



(圖片僅供參考，請以實品為主。)

使用說明與相關注意事項

· 使用前請去除所有包裝 (請勿撕開香氛膠囊蠟上的透氣膜)。
· 擴香效果可能會因空間大小、通風與溫濕度而有所變化。

1	使用前請掀開香氛膠囊蠟的外蓋。	2	將香氛膠囊蠟平放在加熱槽中。
3	將USB電源線的電源接頭插入主體電源孔，USB插頭連接USB插座。	4	連接電源，短按電源開關指示燈亮起即啟動連續恆溫加熱模式。短按第二下電源開關，機器關閉。 ※計時9小時後安全自動關機。
5	燈光模式設定： 當機器啟動後指示燈會保持亮燈，長按電源開關2秒可關閉或重新開啟情境燈。		

· 使用本產品前，請仔細閱讀本說明書。
· 本產品僅能使用SERENE HOUSE香氛膠囊蠟Serene Pod®，勿將液體或其他物品放入加熱槽內加熱。
· 香氛膠囊蠟可重複加熱使用，若香味變淡或效果降低時建議更換新的香氛膠囊蠟；香氛膠囊蠟為耗材，請至各門市或線上購買。
· 如果您有任何身體上的特殊狀況，例如懷孕、肺衰竭、癌症或癲癇等症狀，使用前請向您的醫師徵詢意見。

重要警惕措施


⚠ 注意！

每当使用电器具，必须按照下列次序的指示事项而使用：

- 使用此产品前请细阅使用守则。
- 请勿在本产品运作时将手或手指置于本产品之内。
- 当电源线损坏时，请勿继续使用本产品。
- 使用本产品不当时，将可能导致火灾的意外，请依指示使用本产品，若使用其他介质将可能引发中毒或火灾的危险；请勿将本产品浸入水中，本产品仅供室内使用。
- 香氛胶囊机的电源线极性插头，电源极片有大小之分，如果插头无法完全插入插座时，请转换插头方向，若插头仍然无法接通电源插座，请咨询专业合格的电工人員，切勿自行处理。
- 本产品可接拖线板使用，使用时请注意。
- 连结拖线板时，请注意使用的电器规定，至少与产品规格相同；电源线应放至于明显的地方，避免幼童拉扯或绊倒。
- 除非有专业人士的督導和指示，本产品不适合由身体、感官或精神能力欠佳，或缺乏经验及知识的人士使用（包括儿童）。
- 若电源插头损坏时，请由制造厂或其他服务处或具有相关资格的人员加以更换，以预防意外发生。
- 除非有专业人士的督導和指示，本产品不适合由身体、感官或精神能力欠佳，或缺乏经验及知识的人士使用（包括儿童）。
- 孩童应受监护，以确保孩童不嬉玩电器。建议放在孩童与宠物触及不到的地方，避免意外发生。

产品与配件介绍

· 本产品仅能搭配使用 SERENE HOUSE 香氛胶囊蜡 Serene Pod®，香氛胶囊蜡为单独贩卖商品。



(图片仅供参考，请以实物为主。)

使用说明与相关注意事项

· 使用前请去除所有包装 (请勿撕开香氛胶囊蜡上的透气膜)。
· 扩香效果可能会因空间大小、通风与温湿度而有所变化。


1	使用前请掀开香氛胶囊蜡的外盖。	2	将香氛胶囊蜡平放在加热槽中。
3	将USB电源线的电源接头插入主体电源孔，USB插头连接USB插座。	4	连接电源，短按电源开关指示灯亮起即启动连续恒温加热模式。 ※计时9小时后自动关机。
5	灯光模式设定： 当机器启动后指示灯会保持亮灯，长按电源开关2秒可关闭或重新开启情境灯。		

· 使用本产品前，请仔细阅读本说明书。
· 本产品仅能使用 SERENE HOUSE 香氛胶囊蜡Serene Pod®，勿将液体或其他物品放入加热槽内加热。
· 香氛胶囊蜡可重复加热使用，若香味变淡或效果降低时建议更换新的香氛胶囊蜡；香氛胶囊蜡为耗材，请至各门市或线上购买。
· 如果您有任何身体上的特殊状况，例如怀孕、肺衰竭、癌症或癫痫等症狀，使用前請向您的醫師徵詢意見。

SERENE HOUSE®

香氛膠囊機

操作使用說明書



映叶

