



**Serene Pod® Wireless Scent Diffuser**  
( Wireless Charging Pad included )  
Instruction Manual

**IMPORTANT SAFETY INSTRUCTIONS**

In order to ensure safety and correct usage, please read all the safeguards below as using electric products every time.


**⚠ WARNING**

- When using electric products, basic precautions should always be followed, including the following:
- A.** Do not put the cellphones which do not support wireless charging on the Wireless Charging Pad.
  - B.** Do not apply any other adapters or products which are not made or certified by SERENE HOUSE to this device.
  - C.** Do not put hands, fingers or any other objects into the product while it is in use.
  - D.** To reduce risk of injury, close supervision is necessary when used near children.
  - E.** Please do not use damaged devices or accessories.
  - F.** If the surface-temperature of this device is abnormally high, please do not keep using this product.
  - G.** Failure to follow instructions could result in a fire hazard. The appliance is only to be used with the Serene Pod®. The use of other substances may give rise to a toxic or fire risk. Do not immerse this appliance in water. Wireless Charging Pad is for household use only, Wireless Scent Diffuser is portable.
  - H.** Wireless Scent Diffuser could be powered by connecting with USB or wireless charging pad. Please pay attention to the introductions to electric appliances using. The specifications should be the same.
  - I.** Recommend place the power cord at evident places to avoid children pulling or stumbling, as the power cord is being used.
  - J.** If an extension cord is used, please pay attention to the introductions to electric appliances using. The specifications should be the same.
  - K.** If the power cord is damaged, please stop using it and contact local distributor or related service department for repair or maintenance.
  - L.** Optional: Wireless Scent Diffuser can also be connected with USB Power Adaptor. ( USB power adaptor is NOT included. )

**▲ FOR ADULT USE ONLY. THIS IS NOT A TOY AND IS NOT INTENDED FOR USE BY CHILDREN. KEEP OUT OF REACH OF CHILDREN.**

**Product & Accessories**


- Wireless Scent Diffuser is only applicable to the cellphones which support wireless charging.
- Serene Pod® is required to be used with this product. Serene Pod® is sold separately.



( The image is for reference only. Actual product may vary. )

**Operating Instructions**

Please remove all packaging before use. ( Please do not tear up the woven membrane of Serene Pod®. )



- Please read all instructions carefully before using the product.
- This product is only suitable for Serene Pod®, do not put liquids or other substances into the heating plate.
- Serene Pod® can be heated repeatedly. If the scent fades or the performance drops, please replace new Serene Pod®, Serene Pod® is consumable; please contact your local distributor for more information.
- Stop using the product and open the windows for ventilation. If you have difficulty breathing due to allergic reaction or any special physical conditions, such as pregnancy, lung failure, cancer, epilepsy or other illnesses, please consult your doctor before using this product.

**Cleaning & Maintenance**

- Please disconnect the product from its power source prior to cleaning and maintenance.
- Wait until the product is dry completely after cleaning, then use this product again.
- Do not immerse or wash this product directly, it may cause mechanical malfunction or danger.
- Do not use acidic cleaner, it may cause malfunction to the product.
- Please clean and maintain once a week at least. The lack of maintenance may cause malfunction.



**無限香氛系列產品**  
操作使用說明書

**重要警告事項**

每當使用本產品前，請先閱讀所有警告資訊，確保正確使用。

**⚠ 注意！**

- 請遵循以下警告事項，防止火災、觸電或其他事故。
- A. 請勿將不支援無線充電的手機或香氛膠囊機放至於無線充電感應區上！
  - B. 請勿將非 SERENE HOUSE 製造或認可的變壓器及其他產品或配件應用於本產品。
  - C. 請勿在本產品運作時將手、手指或其他異物放置於本產品之內。
  - D. 為避免危險，幼童須在成年人監督下使用產品，預防意外發生。
  - E. 請勿使用外殼發生破裂的產品及配件。
  - F. 本產品表面溫度異常升高，請立即停止使用。
  - G. 錯誤使用本產品，將可能導致火災的意外，請依指示使用本產品，若使用其他介質將可能引發中毒或火災的危險；請勿將本產品浸入水中，無線充電盤僅供室內使用，無線香氛膠囊機亦可單獨隨身攜帶至各處擴香。
  - H. 無線香氛膠囊機可使用無線充電盤充電運作或使用USB電源線插電運作，但請注意使用的相關電器規定。
  - I. 使用電源線時建議將其放置明顯的地方，避免拉扯與意外發生。
  - J. 無線充電盤與無線香氛膠囊機可接延長線使用，使用時請注意使用的相關電器規定。
  - K. 若電源線損壞時，請勿繼續使用本產品，並請由當地服務處或具有相關資格的人員加以更換以避免危險。
  - L. 本產品所附的USB電源線可支援外接的USB變壓器。( 本產品不含USB變壓器 )。

**▲ 請勿讓兒童獨自使用，建議放在兒童觸及不到的地方，否則有可能造成觸電、受傷。**

**產品與配件介紹**

- 無線充電盤僅適用可相容可無線充電的手機與 SERENE HOUSE 無線香氛膠囊機。
- 本產品僅能搭配使用 SERENE HOUSE 香氛膠囊蠟Serene Pod®，香氛膠囊蠟為單獨販賣商品。



( 圖片僅供參考，請以實品為主。 )

**使用說明與相關注意事項**

· 使用前請去除所有包裝 ( 請勿撕開香氛膠囊蠟上的透氣膜 )。



- 使用本產品前，請仔細閱讀本說明書。
- 本產品僅能使用SERENE HOUSE香氛膠囊蠟Serene Pod®，勿將液體或其他物品放入加熱槽內加熱。
- 香氛膠囊蠟可重複加熱使用，若香味變淡或效果降低時建議更換新的香氛膠囊蠟；香氛膠囊蠟為耗材，請至各門市或線上購買。
- 如果您有任何身體上的特殊狀況，例如懷孕、肺衰竭、癌症或癩癬等症狀，使用前請向您的醫師徵詢意見。

**清潔保養**

- 在清潔保養之前，電器必須切斷電源，並將無線香氛膠囊機自USB電源線或無線充電盤上移除，無線充電盤亦需移除變壓器電源線。
- 清潔完畢，請待完全乾燥後，再使用本產品。
- 清潔保養時請小心，請勿直接浸泡或沖洗本產品，以避免造成機器故障及危險。
- 請勿使用酸性清潔劑，否則有可能導致產品故障。
- 請至少每週清潔保養一次，疏於保養時，有可能引起故障，請務必定期保養。



**無限香氛系列產品**  
操作使用說明書

**重要警惕措施**

每當使用本產品前，請先閱讀所有警告資訊，確保正確使用。

**⚠ 注意！**

- 請遵循以下警告事項，防止火災、觸電或其他事故。
- A. 請勿將不支持無線充電的手機或香氛膠囊機放至於無線充電感應區上！
  - B. 請勿將非 SERENE HOUSE 製造或認可的适配器及其他產品或配件应用于本產品。
  - C. 請勿在本產品運作時將手、手指或其他異物放置于本產品之內。
  - D. 為避免危險，幼童須在成年人監督下使用產品，預防意外發生。
  - E. 請勿使用外殼發生破裂的產品及配件。
  - F. 本產品表面溫度異常升高，請立即停止使用。
  - G. 錯誤使用本產品，將可能導致火災的意外，請依指示使用本產品，若使用其他介質將可能引發中毒或火災的危險；請勿將本產品浸入水中，無線充電盤僅供室內使用，無線香氛膠囊機亦可單獨隨身攜帶至各處擴香。
  - H. 無線香氛膠囊機可使用無線充電盤充電運作或使用USB電源線插電運作，但請注意使用的相关電器規定。
  - I. 使用電源線時建議將其放置明显的地方，避免拉扯与意外发生。
  - J. 无线充电盘与无线香氛胶囊机可接拖线板使用，使用时请注意使用的相关电器规定。
  - K. 若电源线损坏时，请勿继续使用本产品，并请由当地服务处或具有相关资格的人员加以更换以避免危险。
  - L. 本产品所附的USB电源线可支持外接的USB适配器。( 本产品不含USB适配器 )

**▲ 请勿让儿童独自使用，建议放在儿童触及不到的地方，否则有可能造成触电、受伤。**

**产品与配件介绍**


- 无线充电盘仅适用可兼容可无线充电的手机与 SERENE HOUSE 无线香氛胶囊机。
- 本产品仅能搭配使用 SERENE HOUSE 香氛胶囊蜡Serene Pod®，香氛胶囊蜡为单独贩卖商品。



( 圖片僅供參考，請以實品為主。 )

**使用说明与相关注意事项**

· 使用前请去除所有包装 ( 请勿撕开香氛胶囊蜡上的透气膜 )。



- 使用本產品前，請仔細閱讀本說明書。
- 本產品僅能使用SERENE HOUSE香氛膠囊蠟Serene Pod®，勿將液體或其他物品放入加熱槽內加熱。
- 香氛膠囊蠟可重複加熱使用，若香味變淡或效果降低時建議更換新的香氛膠囊蠟；香氛膠囊蠟為耗材，請至各門市或線上購買。
- 如果您有任何身體上的特殊狀況，例如懷孕、肺衰竭、癌症或癩癬等症狀，使用前請向您的醫師徵詢意見。

**清潔保養**

- 在清潔保養之前，電器必須切斷電源，並將無線香氛膠囊機自USB電源線或無線充電盤上移除，無線充電盤亦需移除适配器電源線。
- 清潔完畢，請待完全干燥后，再使用本產品。
- 清潔保養時請小心，請勿直接浸泡或沖洗本產品，以避免造成機器故障及危險。
- 請勿使用酸性清潔劑，否則有可能導致產品故障。
- 請至少每週清潔保養一次，疏於保養時，有可能引起故障，請務必定期保養。

